

DATASHEET

Pencil drawn strain gauge sensor (with Bluetooth and OLED module)

General features


- Easy-to-use
- Small size
- Low cost
- Ecological strain gauge
- Resistance sensor
- Application with resistance values sent thanks to bluetooth
- Rotary encoder included, menu on OLED screen

General description


Pencil drawn strain gauge is first described in Scientific Reports publication “Pencil Drawn Strain Gauges and Chemiresistors on Paper” written by Cheng-Wei Lin*, Zhibo Zhao*, Jaemyung Kim & Jiaying Huang. This sensor aims at reproducing pencil drawn strain gauge in a 4th year Physical Engineering course of National Institute of Applied Sciences (INSA) Toulouse.

Pencil carbon deposited on the paper contains percolated graphite particles network where electrons move. Mechanism enabling electrons to move from grain to grain is tunnelling through potential barrier. However, tunnelling depends exponentially on the length of the barrier. When a mechanical stress is applied to the gauge, grains of percolated network spread away. Thus, when a tension is applied to gauge electrons move less. Resistance increases. When gauge is compressed, electrons move more and resistance decreases.

Strain gauge



The measured resistances are created from gauge drawings printed on paper thick enough to withstand the tensile and compression tests that will be performed. The area to be pencilled in is the dotted one. It has an area of 1.76 cm². The pencils tested will be HB and B. The hardness of the leads is classified as follows:



Hard

Medium

Light

With: **H** = Hard (or dry)

B = Bold (or oily)

HB = Hard Bold (or medium)

F = Fine point (middle of the scale)

Leads are made of clay and graphite. A soft lead, which is on the B side, contains more graphite and less clay than a hard lead, on the H side, which will contain less graphite and more clay.

As explained earlier, drawing on paper creates a thin layer of percolated graphite, which is a granular system. By compressing or pulling the pencil-covered paper, the graphite network is tightened or loosened, respectively. Thus, in compression, the electrons move more easily and the resistance decreases. On the contrary, in traction, the electrons have fewer possible paths to cross the graphite layer on the paper and the resistance increases.

Sensor specifications

| | |
|------------------|------------------------------------------------------------------------------------------------|
| Type | Strain gauge made from paper and graphite particles |
| Materials | <ul style="list-style-type: none"> Paper gauge Paper pencil : 2H and B |
| Sensor type | Strain gauge with PCB shield is passive because power supply is required |
| Measurand | Resistance |
| Measure | Voltage output |
| Resistance range | [11 M Ω ; 4000 M Ω] |
| Time response | 1 resistance value sent every second |

Test Bench

The test bench used is a 3D printed plastic test bench. It is composed of 7 successive half circles, with decreasing radius of curvature. Their respective diameters are as follows: 4.95, 4.45, 3.95, 3.45, 2.95, 2.45, 1.95 cm. Starting from the largest semicircle to the one with the smallest diameter, the paper is laid down by compressing or pulling it, and the resistance is waited for to stabilize before it is noted.






Electrical characteristics


2B

| | | Value | | |
|------------------------|------|-------------------------|----------------|----------------|
| | Unit | Typical (no distortion) | Min distortion | Max distortion |
| Flexion resistance | MΩ | 21 | 37 | 80 |
| Compression resistance | MΩ | 30 | 27 | 13 |

HB

| | | Value | | |
|------------------------|------|-------------------------|----------------|----------------|
| | Unit | Typical (no distortion) | Min distortion | Max distortion |
| Flexion resistance | MΩ | 178 | 229 | 344 |
| Compression resistance | MΩ | 143 | 67 | 28 |






The affine trend line for these curves shows the typical resistance value (without deformation) as the intercept, i.e. $\epsilon = 0$.


Electronic integration circuit



In order to effectively measure the resistance of this strain sensor, we have integrated it into an electrical circuit consisting of a transimpedance operational amplifier and several RC filters to filter out noise. Below is a schematic of the electrical circuit :



- 2 resistances 1 k Ω
- 2 resistances 100 k Ω
- 1 resistance 10 k Ω
- 3 capacitances 100 nF
- 1 capacitance 1 μ Fs
- 1 operational amplifier LTC1050



We then designed this electrical circuit as a shield PCB using KiCad 6.0 software, in order to make it more ergonomic. We incorporated an OLED screen and a rotary encoder which allow to create a menu on which the user can choose the data to display, as well as a bluetooth module which allows to send the data to a mobile phone. Below are the schematics of the shield PCB, as well as a 3D view of the components soldered on it:








Finally, here is the flashcode to download the mobile application that receives the resistance values sent by the bluetooth module.

Android App for Projet_capteur_graphene



Click the button to download the app, right-click on it to copy a download link, or scan the code with a barcode scanner to install.

Note: this link and barcode are only valid for 2 hours. See [the FAQ](#) for info on how to share your app with others.

Dismiss